

CLEANING OUT THE PLUMBING OF YOUR SPA

- 1) Fill spa. Make sure the water is at least 80 degrees and all jets, diverters, and waterfalls are in the open position.
- 2) 1 cup of bleach per 100 gallons of water = run jets for 15 minutes then let it set for ONLY 45 minutes. Do not let it set more than this allotted time.
- 3) Follow directions on back of bottle of Jet Clean. Do not let it sit overnight.
- 4) Wipe entire shell surface and refill.
- 5) Start up regular chemical care routine.

If you have further questions, your spa professional may assist you further.